

# **Randy Rhoads Distortion +**

A tribute to Randy Rhoads' monumental legacy, this pedal has been painstakingly matched to the legend's own MXR Distortion+ to recreate the same raw, overdriven tones heard on his most beloved hits.

### **External Controls**



- 1 OUTPUT knob controls overall volume of effect
- 2 DISTORTION knob controls amount of distortion
- 3 FOOTSWITCH toggles effect on/bypass (red LED indicates on)

### **Basic Operation**

#### **Power**

The MXR® Randy Rhoads Distortion + is powered by one 9-volt battery (remove bottom plate to install), a 9-volt AC adapter such as the Dunlop ECB003/ECB003EU, or an MXR Brick™ Series power supply.

#### **Directions**

- 1 Run a cable from your guitar to the Distortion+'s INPUT jack and run another cable from the Distortion+'s OUTPUT jack to your amplifier.
- 2 Start with all controls at 12 o'clock.
- 3 Turn the effect on by depressing the footswitch.
- 4 Rotate OUTPUT knob clockwise to increase overall volume of effect or counterclockwise to decrease it.
- 5 Rotate DISTORTION knob clockwise to increase amount of distortion or counterclockwise to decrease it.

## **Specifications**

Input Impedance	1ΜΩ
Output Impedance	25kΩ
Bypass	True Hardwire
Current Draw	11 mA
Power Supply	DC 9 volts

<sup>\*</sup> Output control at mid position